

Mellotron M4000D Soundcard 08, page 1 of 3

Here is the sound list for the seventh Digital Mellotron expansion card, Soundcard 08. Soundcard 01 is the internal card. The looped Music Master and M1 sounds are looped version of the sounds that are on card 03. Soundcard 08 contains a total of 116 Chamberlin sounds plus eight sounds provided by Blonde Redhead and four sounds provided by Woodrow Jackson. Many thanks for keeping the Mellotron Sound Library alive!

Music Master 500 Rhythms/Accompaniments, LOOPED (complete, 18 sounds)

Fox Trot 1	168	Marimba
Viennese Walz	168	Pizz Violins
Walz	84	Celeste
Rhumba	126	Accordion
Polka	126	Clarinets Fill
March	126	Brass 1
Dixieland	152	Dixieland Fill 1 (on the beat)
Foxtrot 2	152	Saxes on afterbeat
Foxtrot 3	152	Dixieland Fill 2
Foxtrot 4	232	Brass 2
Cha-Cha	116	Flutes Fill
Foxtrot 5	116	Violins
Foxtrot 6	215	Brass Fill
Beguine	108	Marimba Fill
Tango	108	Sound Effects
Foxtrot 7	132	DoWa Brass
Samba	132	Steel Guitar
Foxtrot 8	132	Sound Effects

Music Master 600/600 Rhythms, LOOPED (17 sounds with 25 unique rhythms, 12 repeated)

Viennese Walz	168
Pipe Organ Bass	0
Walz	84
Polka	126
Tuba and Drums	100
Rhumba	126
Fox Trot 1	152
Shuffle	116
Fox Trot 2	72
Fox Trot 3	184
Fox Trot 4	96
Tango	108
Tambourine Rhythm	116
Fox Trot 5	200
Samba	132
Cha-Cha	116
Rock-Roll	132

Music Master 600 Lead Sounds (13 sounds)

Muted Trombone MM600
Accordion MM600
Kinura MM600
Organ C2 MM600
Organ C3 MM600
Accordion MM600, Left Keyboard (also M1)
ChimesBirds MM600, Left Keyboard
Vibraphone MM600, Left Keyboard
Organ B3 MM600, Left Keyboard
Organ C1 MM600, Left Keyboard
Organ C2 MM600, Left Keyboard
Organ C3 MM600, Left Keyboard
WaWaTrumpet MM600, Left Keyboard

Mellotron M4000D Soundcard 08, page 2 of 3

Lead sounds recorded at the time of the Music Master, but not used, LOOPED (29 sounds)

Violin Dirty
Violin Dirtier
Viola 2
Viola 3
Viola Tremolo
Cello Fast Vibrato
Cello KOCS1
Cello KOCS2
Cello Short
Bass Pizzicato / Trombone
Female Solo Voice 2
Accordion Dirty
Bassoon Lo
Bassoon Hi
Bass Clarinet 2
Recorder Lo
Recorder Hi
Trombone Open 2
French Horn 2
Trumpet Unreleased 1
Trumpet Unreleased 2
Trumpet Unreleased 3
Trumpet Unreleased 4
Organ Tremolo 1
Organ Tremolo 2
Organ Tremolo 3
Organ Kinura 2
Marimba M1 HiFi
Mandolin 3

Mellotron M4000D Soundcard 08, page 3 of 3

M series Lead Sounds, LOOPED (21 sounds, M denotes certain use in the M-series instruments)

Dixieland M
Violin Solo
Violin Damped
Violin Vibrato
Violin Staccato
Violin 2 Bowed
Doo Vocal
Alto Sax M
Tenor Sax 2
Tenor Sax 3 M
English Horn M
Soprano Sax M
Trumpet no Vibrato
Muted Trumpet M
Trombone 2 M
Flute String Organ M
Kinura Organ M
Guitar Tremolo
Banjo M
Mandolin Harry
Steel Guitar Slur (M1 sound, new, not looped)

Gino Vanelli Library, LOOPED (18 sounds, recorded for the M series)

Violins Light Vibrato
Violins Regular Vibrato
Violins Half Trill
Violins Whole Trill
Violins Tremolo
Viola Light Vibrato
Viola Regular Vibrato
Viola Half Trill
Viola Whole Trill
Viola Tremolo
Cello Light Vibrato
Cello Regular Vibrato
Cello Half Trill
Cello Whole Trill
Cello Tremolo
Bass Light Vibrato
Bass Regular Vibrato
Bass Tremolo

Custom recorded sounds (12 sounds)

Clavinet Lo Blonde
Clavinet Hi Blonde
Harpichord Blonde
Piano Blonde
Rhodes Blonde
VSS 01 Blonde
VSS 02 Blonde
VSS 03 Blonde
Bowed Vibes Woody
Degan Shaker Fast Woody
Degan Shaker Slow Woody
Degan Shaker Single Woody